

SAFETY FIRST

**Be sure to wear proper eye protection when cutting the Sure-Board® Series 200
(All cutting of Sure-Board® Series 200 is suggested from the sheet steel or back side.)**

Type of Cut Required:

Full length or width cutting:

- 1) Set blade depth to maximum 1/8" depth and score steel only.
- 2) Cut steel sheet for required length with skilsaw.
- 3) Score gypsum with razor knife, bend over to score paper on face side.
- 4) Snap cut-off piece and clean up edge with rasp if necessary.
- 5) Hang Sure-Board® as you would regular gypsum and screw off.

Partial length or width, outlets and opening cuts:

- 1) Set blade depth to maximum 1/8" depth and score steel only.
- 2) Cut steel where necessary, minimal over-cutting may be required at corners.
- 3) Peel off steel in required areas and hang Sure-Board® Series 200 panel as you would a regular gypsum panel, and tack to studs.
- 4) Use router to cut off unwanted gypsum at opening or outlet, and complete the screwing of the Sure-Board® at the prescribed spacing.

**All cutting of Sure-Board® may be viewed on our Website:
www.sureboard.com or we would be pleased to send you a copy of our
installation video upon request.**

Cemco

Technical Support Department (800) 775-2362

Corporate Offices / Main manufacturing Plants *
263 Covina Lane, City of Industry, California 91744*
1001-A Pittsburg Antioch Hwy, Pittsburg, California 94565*
490 Osage Street, Denver, Colorado 80204